

How to disable or enable the touchpad?

The touchpad on a laptop is a convenient way to add the functionality of a mouse without needing an extra [peripheral](#). When the touchpad is enabled or unlocked, the touchpad has the same functionality as an external [mouse](#). When the touchpad is disabled or locked, the touchpad doesn't work, preventing the [mouse cursor's](#) accidental movement with your palm while typing. When disabled, the need for an external mouse is required.

1. Press the [Windows key](#), type **touchpad**, and press [Enter](#).
Or, press `Windows key+I` to open Settings and choose **Devices**, then **Touchpad**.
2. In the *Touchpad Settings* window, click the **Touchpad** toggle switch to the **Off** position

However considering you have already purchased Restoro and would like us to assist you in doing that utilizing a remote session, please contact our support and they will be happy to help you.

Email: support@restoro.com

Revision #1

Created 2 years ago by [Ghichel Santos](#)

Updated 2 years ago by [Ghichel Santos](#)