

What to do if mouse cursor is moving on its own?

Sometimes your Windows 10 laptop or desktop cursor will start moving on its own, disrupting your work or browsing. Here are a couple potential ways to fix it from Microsoft.

- **Run hardware troubleshooter.** Press **Windows + X**, and select **Control Panel**. Go to **Troubleshooting**, and on the left panel click **View all items**. Select **Hardware and devices troubleshooter** and follow the instructions.
- **Update the mouse and other pointing device drivers.** Press **Windows + R**, type **devmgmt.msc** and hit **Enter**. Expand **Mice and other pointing device drivers**. Right click on the driver of your mouse, and click **update**.

However considering you have already purchased Restoro and would like us to assist you in doing that utilizing a remote session, please contact our support and they will be happy to help you.

Email: support@restoro.com

Revision #1

Created 3 years ago

Updated 3 years ago